




## HPSHEAD-P Parts Breakdown

| <u>Key</u> | <u>Part #</u> | <u>Description</u>          |
|------------|---------------|-----------------------------|
| A          | 733024        | Power Cord                  |
| B          | 410129        | Strain Relief Bushing       |
| C          | 403003        | ON-OFF Switch               |
| D          | 160718T       | Lamp Housing Bracket        |
| E          | 160719T       | Igniter                     |
| F          | 160720T       | Ballast                     |
| G          | 160721T       | Igniter/Ballast Compartment |
| H          | 203003Y       | Light Diffuser Grille       |
| I          | 160722T       | Lamp Socket                 |
| J          | 160723T       | Lamp Socket Ring            |
| K          | 160724T       | DLHPS Reflector/Housing     |