



MARQUE

Vision Comes to Life

Non Priced 4683-84

DEALER: Marque Factory

CUSTOMER: Open

Exp. Date: 02/21/2012
 Quote No: 10068-0001
 Job/Order No: 4683-84
 AMBULANCE: MA-1-148CO Type I Model 148 Commando

09/17/2012

Page 1

| PART NO | S | DESCRIPTION | QTY | ID |
|------------|---|--|-----|-----|
| | | == Type I Model 148 Commando - 1.000 09/20/11 == | 1 | SJC |
| | | 4683 VIN 1FDUF4HT1CEB45198 | | |
| | | 4684 VIN 1FDUF4HT4CEB79880 | | |
| 00-00-0020 | | Order Coordinator - Michele Yoder - (574) 970 6774 | 1 | SJC |
| | | AMBULANCE CONVERSION | 1 | SJC |
| 03-35-0110 | | 2012 Conversion, Type I, Model 148 Commando | 1 | SJC |
| 04-20-0430 | | /-- Conversion, Type I, Headroom, 72" ILO 68" | 1 | SJC |
| 04-10-1000 | S | /-- Change to Standard Dimensions (Per Inch) | 4 | SJC |
| 04-20-2430 | | /-- Conversion, Type I, Body Width, 96" ILO 93" | 1 | SJC |
| 04-10-1000 | | /-- Change to Standard Dimensions (Per Inch) | 3 | SJC |
| 04-20-4050 | | /-- Conversion, Type I, Body Length, 154" ILO 148" | 1 | SJC |
| 04-10-1000 | | /-- Change to Standard Dimensions (Per Inch) | 6 | SJC |
| | | CHASSIS | 1 | SJC |
| 05-20-0330 | | Chassis, 2012 Ford F-450SD XLT, 4x4, 165" WB, Diesel F4674 | 1 | SJC |
| 06-00-0110 | | /-- OEM Supplied - Jack w/handle | 1 | SJC |
| 06-00-0120 | | /-- OEM Supplied - Lug Wrench | 1 | SJC |
| 06-00-0410 | | /-- Running Boards, One (1) Pair ADP (Type I) | 1 | SJC |
| 12-55-0110 | | /-- Mudflaps, Front, Included with Running Boards | 1 | SJC |
| 06-20-0100 | | /-- OEM Mirrors STD | 1 | SJC |
| 06-50-0700 | | /-- Suspension, Rear Air Ride, Link Electrical F | 1 | SJC |
| | | Marque to wire a magnetic switch so that system dumps with the left rear entry door - reinflates when closed - replace the manual drain valve and lanyard with a Velvac auto-drain valve | | |
| | | 8M000097 - Unit for F450.F550 | | |
| | | 800M1074 - Electronic Control Panel | | |
| | | 800M1200 | | |
| | | 800M1071 - Electronic Sensor Kit | | |
| | | 13010559 - Heated Drain Valve | | |

| PART NO | S | DESCRIPTION | QTY | ID |
|------------|---|--|-----|-----|
| 06-50-1000 | | <i>/-- Suspension, Rear Air Ride, Installed Prior to Body Mounting</i> | 1 | SJC |
| 06-50-1110 | | <i>/-- Suspension, Rear Air Ride, Dump Override Switch IATS</i> On/Off style switch - in "on" position allows the air ride to kneel when the left rear entry door is open. In the "off" position, prevents the suspension from kneeling. Install air ride switch on the curbside wall by the rear doors. | 1 | SJC |
| 90-14-0110 | | <i>/-- Air Ride Suspension Safety Sign (Standard)</i> Installed in the cab per Engineering Bulletin #044 "WARNING - Driving this vehicle without air in the rear suspension could cause loss of vehicle control and/or damage to the suspension." 2" x 4" White lettering on red background | 1 | SJC |
| 06-60-0200 | | <i>/-- Rubberized Vinyl Cab Flooring STD</i> | 1 | SJC |
| 06-70-0100 | | <i>/-- Spare Tire, Shipped Loose</i> Deletes the mounting bolt, nut and plate | 1 | SJC |
| 06-70-5600 | | <i>/-- Wheel Sims - Phoenix 19.5", Set of Four (4)</i> | 1 | SJC |
| 06-80-0130 | | <i>/-- Air Fill Extensions, Rear Tires (19.5"), Phoenix "Air Max"</i> installed per the manufacturer's instructions Phoenix #AMH1 | 1 | SJC |
| 12-70-0110 | | <i>/-- DEF/Urea Tank Fill Bezel</i> Cast# FG4503-6S163-A Ford (118232) Cast# FG4503-6S163 Chevy (118162) | 1 | SJC |
| 31-10-0110 | | <i>/-- Idle Control, OEM Electronic Throttle (Standard)</i> Set RPM of 1450 | 1 | SJC |
| 36-10-0105 | | <i>/-- Cab/Chassis Lighting Package, Ford F450</i> | 1 | SJC |
| 37-15-0210 | | <i>/-- Warn. Light, Grille, Pass. Side, Whel 500 LED Warn. Ford F, Cast</i> | 1 | SJC |
| 49-29-2015 | | <i>/-- Whelen, 500 TIR6, Red, LED, Clear Lens w/o flange</i> 50R03ZCR | 1 | SJC |
| 50-00-3200 | | <i>/-- Grille Bezel, Cast, F-Series Ford, Pass. Side</i> Cast LH52611-1 (118189) | 1 | SJC |
| 50-00-8200 | | <i>/-- Deutsch water proof connector</i> | 1 | SJC |
| 37-25-0210 | | <i>/-- Warn. Light, Grille, Driver Side, Whel 500 LED Warn. Ford F, Cast</i> | 1 | SJC |
| 49-29-2015 | | <i>/-- Whelen, 500 TIR6, Red, LED, Clear Lens w/o flange</i> 50R03ZCR | 1 | SJC |
| 50-00-3210 | | <i>/-- Grille Bezel, Cast, F-Series Ford, Driver Side</i> Cast LH52612-1 (118188) | 1 | SJC |
| 50-00-8200 | | <i>/-- Deutsch water proof connector</i> | 1 | SJC |
| 37-35-0610 | | <i>/-- Warn. Light, Inters., Pass Side, Whel 500 LED Warn. 15° F450, Cast</i> | 1 | SJC |
| 49-29-2215 | | <i>/-- Whelen, 500 TIR6, Red, LED, Clear Lens w/flange</i> 50R03ZCR (115766) | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|---|---|---|-----|-----|
| 50-00-1040 | | <i>/-- Whelen, 500 series Chrome Flange</i> 5GE8LRC | 1 | SJC |
| 50-00-8200 | | <i>/-- Deutsch water proof connector</i> | 1 | SJC |
| 37-45-0610 | | <i>/-- Warn. Light, Inters., Driver Side, Whel 500 LED Warn. 15° F450, Cast</i> | 1 | SJC |
| 49-29-2215 | | <i>/-- Whelen, 500 TIR6, Red, LED, Clear Lens w/flange</i> 50R03ZCR (115766) | 1 | SJC |
| 50-00-1040 | | <i>/-- Whelen, 500 series Chrome Flange</i> 5GE8LRC | 1 | SJC |
| 50-00-8200 | | <i>/-- Deutsch water proof connector</i> | 1 | SJC |
| 55-18-0112 | | <i>/-- Siren Speakers, Ford 2011 F-Series</i> 118192 118193 | 1 | SJC |
| 57-18-0110 | | <i>/-- Booster Pump - 12V Ford F Series</i> Install in the water supply line to the heater Pro Air #80 000 990 (118628) Ford F series Only | 1 | SJC |
| 69-06-0500 | | <i>/-- Console, Cab, MultiSpec Aluminum</i> Include in the console map book storage and cup holders | 1 | SJC |
| 69-10-2040 | | <i>/-- Multispec Color: Greystone MS99-6072</i> MS99-6072 | 1 | SJC |
| 05-20-0351 | X | AC Controller for Type I F Series Chassis Intermotive (SJC 118909) ACVC502A | 1 | |
| CHASSIS COMPONENTS AND ACCESSORIES | | | | |
| 06-50-2000 | | Front End Alignment, Chassis Pre-Delivery w/Printed Report | 1 | SJC |
| MODULE CONSTRUCTION | | | | |
| 08-10-0100 | | Roof Construction, 4"x4" formed channel @ 16" o.c. (Standard) | 1 | SJC |
| 08-20-0140 | | Wall Construction, 2x2's @ 12" o.c. (Type I) | 1 | SJC |
| 08-30-0110 | | Pass-Thru, Type I, w/ Sliding Plexi Window Sliding window to be framed on the module side using extruded aluminum sliding cabinet door framing components | 1 | SJC |
| 08-50-0130 | | Floor Construction, Composite (No Wood) ILOS PDG Associates - 3/4" Coosa bluewater 20 - 5x12 sheets (116063) | 1 | SJC |
| 08-60-0100 | | Body-to-Chassis Mounting, Type I (Standard) | 1 | SJC |
| UNDERCOATING and INSULATION | | | | |
| 10-00-0100 | | Undercoating, Underside of Module Floor (Standard) | 1 | SJC |
| 10-10-0100 | | Insulation, Walls and Ceiling, R11 Fiberglass Batt (Standard) | 1 | SJC |
| 10-10-0410 | | Insulation, Entry Doors, Spray Foam Yoder Insulation | 1 | SJC |
| 10-10-0750 | | Insulation, Floor, Reflectix Foil Lined Bubble Wrap Reflectix foil lined bubble material to be installed facing the ground - glue in-place - cover bottom side of floor w/ .060" aluminum - seal any gaps | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|-------------------|---|--|----------|------------|
| | | Lowes (SJC 106610) | | |
| | | EXTERIOR BODY TRIM and ACCESSORIES | | |
| 12-05-0100 | | Drip Rail Trim Mouldings Over Door Openings (Standard) Mouldings to extend no more than 1/4" beyond each side of the door openings | 1 1 | SJC SJC |
| 12-10-0100 | | Stone Guards, ADP, Front Wall (Standard) ADP installed on the lower portions of the front wall, outboard of the chassis - see prints | 2 | SJC |
| 12-20-0100 | | Rub Rails, Skirt Line, One (1) Set ADP | 1 | SJC |
| 12-30-0100 | | Fenderettes, One (1) Pair Rubber | 1 | SJC |
| 12-35-0100 | | Fuel Fill Bezel, Cast Aluminum (Standard) Cast Products #FG2101-1-250 (Ford / Chevy Type I) (107231) #FG5301-1-250 (Ford / Chevy Type III) (107397) | 1 | SJC |
| 12-40-0200 | | Rear Bumper, Grip Strut Folds-Up Into Pocket In Rear Riser See prints. This will be 7" bumper pods and 7" grip strut. | 1 | SJC |
| 12-40-1010 | | Bumper Guards, Rear, One (1) Pr. Extruded Rubber, 10"w x 2"h Orr and Orr H-9405 (115773) 2 Req. | 1 | SJC |
| 12-45-0100 | | Rear Riser, ADP (Standard) | 1 | SJC |
| 12-50-0100 | | License Plate Bracket, Recessed (Standard) When mounting bracket, please put ECK on all mounting screws. Cast Products #LP0002-1 | 1 | SJC |
| 50-00-8100 | | -- License Plate Light, LED Optronics UCL-11CKB | 1 | SJC |
| 12-55-0500 | | Mudflaps, Rear, One (1) Pair Rubber, w/Logo w/ Marque Logo Dura Guard #26205925R | 1 | SJC |
| | | COMPARTMENT CONSTRUCTION and COMPONENTS | | |
| 14-10-0110 | | Compartment Seams Fully Welded ILOS Paint with Silver paint after welding. Compartments are to be welded on the INSIDE not outside. | 1 5 | SJC SJC |
| 14-15-0120 | | Streetside-Front Compartment (#1), ADP, Sweep-out ILOS .125" ADP Add cut out and removable panel to forward wall of compartment. Attach with 10x24 rev-nuts. Place foam tape behind panel to prevent rattling. | 1 | SJC |
| 14-20-0100 | | Streetside #2 Compartment, ADP, Sweep Out (Std.) .125" ADP, sweep-out floor | 1 | SJC |
| 69-36-0100 | | -- CPR Seat w/ Hinged Backrest and Seat (STD) Includes lap style seat belt | 1 | SJC |
| 14-35-0300 | | Streetside-Rear Compartment (#4), ADP, Sweep-out ILOS .125" ADP | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|---------------------|---|---|-----|------------|
| 14-45-0130 | | Curbside-Rear Compartment (#5), ADP, Sweep-out ILOS .125" ADP | 1 | SJC |
| 14-60-0120 | | Side Entry Stepwell, Type I, ADP (Standard) Tube support welded in with audioguard sprayed over it. | 1 | SJC |
| 14-60-0210 | | /-- Stepwell, Side Entry, Removable Grip Strut Insert IATS Recessed removable grip strut section w/drain hole | 1 | SJC |
| 14-65-0100 | | ALS Compartment Door (#8) | 1 | SJC |
| 14-80-0110 | | Compartment Size, Other Than Standard See prints | 2 | SJC |
| | | SS rear and CS rear | | |
| 15-10-0310 | | L-Shape Backboard Holder Allow 3" of space per backboard holder between compartment wall and any compartment dividers | 2 | SJC |
| 15-10-0650 | | /-- Move Comp't. Divider due to Backboard Holders (PN) Move any vertical divider next to the backboard holders to allow 3" for space per specified backboard holder | 2 | SJC |
| 15-10-0420 | | Vertical Divider, Fixed, Smooth Aluminum ILOS SS1 compartment - DA finish Divider shall be 13" deep on 19 1/4" compartments Divider shall be 14" deep on 20 1/4" compartments Above measurements include the rod | 1 | SJC |
| 15-10-1000 | | Adjustable Shelf in SS#2 (Standard) .125" smooth aluminum, includes four shelf brackets and black pinch trim installed on the outside edge of the shelf | 1 | SJC |
| 15-10-1110 | | Adjustable Shelf IATS (1) SS2 and (2) SS3 | 3 | SJC |
| 15-10-1210 | | Compartment Adjustable Shelf Tracks, Unistrut Thomas-Austin: Channel: 107204 Channel nuts: 107250 | 1 | SJC |
| 15-10-1800 | | Plastic Tiles on Compartment / Shelf Floors Includes Mate flex matting on all compartments, shelves, and trays Mateflex Versaflex - Black (115777) | 1 | SJC |
| 15-10-1830 | | /-- Plastic Tile Color - Black (STD) Mateflex Versaflex - Gray ILOS | 1 | SJC |
| | | MODULE DOOR CONSTRUCTION and COMPONENTS | | |
| 16-10-0100 | | Extruded/Pan Formed Hybrid Doors (Standard) | 1 | SJC |
| 16-10-0300 | | /-- Electrical Feed to All Doors - Curly Cord | 1 | SJC |
| 16-10-0160 X | | Add Rubber gaskets to all Eberhard latches. | 1 | SJC |
| 16-20-0100 | | Compartment and Entry Door Latching Hardware (Standard) Compartment doors in excess of 23" tall shall receive dual nadir pins | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|----------------|---|--|-----|-----|
| 16-20-0130 | | Compartment Door Handles, Eberhard | 5 | SJC |
| 16-00-0600 | | /-- Eberhard, Chrome Exterior Locking SJC 115519 handle SJC 11537/73 rotary latch SJC 119081/j-20 brass door rod connector to prevent door rattle (TH2989) | 5 | SJC |
| 16-22-0120 | | Curbside Entry Door | 1 | SJC |
| 16-22-1100 | | /-- Curbside Entry Door Handles, Eberhard | 1 | SJC |
| 16-00-0600 | | /-- Eberhard, Chrome Exterior Locking SJC 115519 handle SJC 11537/73 rotary latch | 1 | SJC |
| 16-00-0610 | | /-- Eberhard, Interior Locking SJC 115370 | 1 | SJC |
| 16-22-2000 | | -- Curbside Entry Door Closer - Gas Strut | 1 | SJC |
| 16-24-0120 | | Rear Entry Doors | 1 | SJC |
| 16-24-1100 | | /-- Rear Entry Door Handles, Eberhard | 1 | SJC |
| 16-00-0600 | | /-- Eberhard, Chrome Exterior Locking SJC 115519 handle SJC 11537/73 rotary latch | 1 | SJC |
| 16-00-0610 | | /-- Eberhard, Interior Locking SJC 115370 | 1 | SJC |
| 16-00-0620 | | /-- Eberhard, Interior Non-Locking SJC 115371 | 1 | SJC |
| 16-24-3300 | | /-- Entry Door Handle, Eberhard IATS Install exterior paddle handle of the left-rear entry door - deletes the interior pivot plate assembly | 1 | SJC |
| 16-00-0630 | | /-- Eberhard Chrome Exterior Non-Locking SJC 115368 Handle SJC 115372/73 rotary latch | 1 | SJC |
| 16-24-3000 | | -- Rear Entry Doors, Cast Grabber Door Checks (Standard) Cast Products DH0017 | 1 | SJC |
| WINDOWS | | | | |
| 16-30-0100 | | Window, Side Entry Door, Upper, Dark Tint black frame | 1 | SJC |
| 16-35-0010 | | -- Window, 19" X 18" Dark Tint Slider Clear Vision Windows: 9FM500026 | 1 | SJC |
| 16-35-0200 | | -- Clamp Ring - Window 19" X 18" - 2.28" Wall Clear Vision Windows: 9PCR00001 | 1 | SJC |
| 16-30-0600 | | Window, Rear Entry Door, Upper, Dark Tint black frame | 2 | SJC |
| 16-35-0030 | | -- Window, 19" X 18" Dark Tint Fixed Clear Vision Windows: 9FMI00051 | 2 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|--|---|---|-----|-----|
| 16-35-0200 | | -- Clamp Ring - Window 19" X 18" - 2.28" Wall Clear Vision Windows: 9PCR00001 | 2 | SJC |
| REFLECTORS | | | | |
| 16-40-0120 | | 1" x 4" Reflector - Red (standard) installed on the lower rear of the streetside and curbside walls just above the rubrail and in the right corners of the rear wall just above the rear riser. Grote 40132-3 | 1 | SJC |
| 16-40-0530 | S | Compartment Door LED Warning Lights - Installed at bottom of doors - see prints - lights are to flash whenever the compt doors are open. | 5 | SJC |
| 50-00-7220 | S | -- Optronics 4" Amber LED Recessed in each front hinged compartment door liner. These will flash when the compt door is open and flash independent of all the others. Optronics STL43ABX Amber 10 diode or equal | 5 | SJC |
| MISCELLANEOUS BODY COMPONENTS ELECTRICAL FEATURES and COMPONENTS 12 VOLT POWER COMPONENTS | | | | |
| 31-10-0120 | | 12 Volt Load Center Location [J-Box] (Standard) | 1 | SJC |
| 31-10-0200 | | 12 Volt Electrical System, FirstTronics | 1 | SJC |
| 31-00-0100 | | -- 12 Volt Electrical System, FirstTronics 107358,59,60 - Communication Cables 107346 - Front Panel 107348 - Rear Panel 107421 - Power Distribution 107347 - Electronic Control Board | 1 | SJC |
| 31-10-0350 | | -- Warning Light Sequencer System FirstTronics Sequencer to operate on load start-up only 107349 | 1 | SJC |
| 31-15-0195 | | -- Driver's Control Console Gauges FirstTronics incorporated in the front switch panel | 1 | SJC |
| 53-12-0105 | | -- Warning Light Flasher, Vanner 5860GCPE (Standard) 5860GCPE (117140) | 1 | SJC |
| 53-16-0100 | | -- Warning Light Flash Pattern, K-Spec | 1 | SJC |
| 31-10-0510 | | Power Locks for Module Entry Doors Includes actuator, actuator connector, actuator pigtail, relay connector - one switch installed on CS wall just inside the side entry door, one switch installed on the rear wall just inside the CS rear entry door Includes tie in to OEM cab chassis doors (including Key faubs if chassis is so equipped) | 1 | SJC |
| 31-10-0530 | | Power Locks for Compartment Doors Includes actuator, actuator connector, actuator pigtail, relay connector - Use same switch as entry doors | 5 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|------------|---|--|-----|-----|
| 31-10-0560 | | Remote Power Switch to Activate Cab & Module Door Locks In the grille Cole Hersee 55065-03 Switch and Cole Hersee rubber boot 81264 | 1 | SJC |
| 31-20-0120 | | Module Power Disconnect Switch, TST Remote mounted in the J-box and wired to operate with the ignition switch w/ 5 minute delay unless indicated otherwise TST CDR-357 | 1 | SJC |
| 31-20-0300 | | Battery Charger/Converter, Pre-Wire (Type I) Includes a power and ground lead terminated in the SS#2 compartment - if inverter w/ battery charger is also specified, route wiring to the location specified in the inverter option | 1 | SJC |
| 31-25-0100 | | 12 Volt Recepts, Cigarette Lighter Style, Two(2) | 1 | SJC |
| 31-00-0400 | | /-- 12 Volt Recepts, Cigarette Lighter Style (1) in the Action Area, (1) in the ALS cabinet unless specified otherwise SJC #115351 | 2 | SJC |
| 31-25-0210 | | Speakers, for AM/FM Radio, One (1) Pair Ceiling Mounted see prints (2) speakers with Fader MCM Electronics 50275- Switch #107462 MCM Electronics 50110- Knob #107463 | 1 | SJC |
| 16-50-0120 | | /-- Backer Plates for OEM Speakers For 12" tube spacing - OEMSPKC012"OC For 16" tube spacing - OEMSPKC016"OC | 2 | SJC |
| 31-25-0300 | | Clock, Analog, Battery Operated, Trin-Tec | 1 | SJC |
| 31-00-0500 | | /-- Clock, Analog, Battery Operated, Trin-Tec Installed on rear wall CS of rear doors - attached w/ 3M Dual-Loc fasteners - includes AA battery (115988) | 1 | SJC |
| | | 110/220 VOLT WIRING AND COMPONENTS | | |
| 32-10-0100 | | 110 Volt AC Wiring And Components Electrical system - 120-Volt | 1 | SJC |
| 32-12-0110 | | Block Heater Switch IATS Install in the JBox SWITCH: Grainger 5C325 - 15A/120V red w/ internal pilot light PLATE: KEVCO S1 stainless steel LABEL: Grayson Graphics "BLOCK HEATER" - 1/2" x 1.5" - white letters on red vinyl | 1 | SJC |
| 32-14-0700 | | Shoreline, 20A Kussmaul "Super Auto-Eject" Inlet, Cover and Connector: Kussmaul Electronics 091-55-20-120 Interrupter: Internal (107636) | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|------------|---|--|-----|-----|
| 32-22-0120 | | Shoreline Light, Positron, White on Black Red Back-lit LED wired to operate if the shoreline breaker is set, turns off when tripped | 1 | SJC |
| | | M401005 (116855) 20 AMP M401009 (117346) 30 AMP | | |
| 32-26-0110 | | Inverter, Pre-Wire (Standard) | 1 | SJC |
| 32-26-0115 | | Refer to Part #31-20-xxxx for Specific Inverter Information | 1 | SJC |
| 32-30-0100 | | Recepts, 110V AC Hospital Grade Duplexes | 1 | SJC |
| 32-00-0100 | | /-- Recepts, Interior 110V AC Hospital Grade Duplex (1) in Action Area, (1) in Defib. area, (1) in ALS cabinet | 3 | SJC |
| | | Recept: Wesco 8200HLI (115776) Box-Recessed Wesco 9301E (105476) Flush (105534) Cover Wesco SS8 (105510) | | |
| | | INTERIOR LIGHTING and COMPONENTS | | |
| 33-10-0110 | | Dome lights, Dual Filament Incandescent, Six (6) | 1 | SJC |
| 33-00-0110 | | /-- Dome lights, Dual Filament Incandescent, Weldon Weldon 8040-0520-080 w/1157 bulb (106012) | 6 | SJC |
| 16-50-0110 | | /-- Backer Plates for Dome lghts For 12" tube spacing - DLC012"OC For 16" tube spacing - DLC016"OC | 6 | SJC |
| 33-10-0191 | | Dome Lights, Streetside Activate on Opening of Entry Doors Streetside dome lights shall automatically light on their "low" setting when the rear entry doors or the side entry door is opened. | 1 | SJC |
| 33-10-0245 | | Fluorescent Light(s), 36" Thin-Lite #718XL, Two (2) | 1 | SJC |
| 33-00-0640 | | /-- Fluorescent Light(s), 36" Thin-Lite #718XL see print for location - requires backer plates in ceiling | 2 | SJC |
| | | Gustafson: Thin-Lite 718XL (116054) | | |
| 16-50-0100 | | /-- Backer Plates for Fluorescent Lights | 2 | SJC |
| 33-10-0370 | | Timer, 60 Minute w/o Hold Feature installed in the curbside wall adjacent to the side entry door - see prints | 1 | SJC |
| | | Fluorescent timer Wesco FF60M (106773) | | |
| 33-10-0620 | | Light, Side Entry Stepwell, (1) Recessed 2.5" 9 diode LED installed in the right forward stepwell wall - light housing must be sealed against the treadplate using butyl tape to prevent water intrusion | 1 | SJC |
| 53-30-0140 | | /-- 2.5" Recessed 9 diode LED Maxxima #LED-963CL - Clear 9 diode (116124) R963-CH chrome bezel (115969) | 1 | SJC |
| 33-10-0720 | | Entry Door LED Warning Lights, Rectangular Installed at bottom of entry doors - see prints - lights are to flash whenever the module entry doors are open and battery power is enabled. If | 1 | SJC |

| PART NO S | DESCRIPTION | QTY | ID |
|--|---|----------|-------------------|
| | this is not a multiplex system, it will also require a wigwag flasher and three (3) 4-prongs relays. Add magnetic switch to left entry door leaf. | | |
| 50-00-7500 | /-- LED 1.6"x4.5" Rectangular Warning Lights Truck-Lite LED Model 18 #18050R | 3 | SJC |
| 33-10-0830 | Action Area Light, Liteco 12" Pulsar Fluorescent wired to a switch in the AA switch panel - order w/ warm white bulbs Liteco #17612195 (117253) | 1 | SJC |
| 33-10-1010 | Spotlight, Handheld, Optronics "BlueEye", 400,000 CP (Std.) Hard wired under the cab console Fasten wire with PClamp at rear of seat base. Optronics KB4003 (108555) | 1 | SJC |
| 33-10-2010 53-30-0180 | ALS Cabinet Lights, Rectagular Surface Mount Dual Bulb Incandescent -- Rectagular Dual Bulb Incandescent w/Clear Lens Vans 1211W (106550) | 2 2 | SJC SJC |
| EXTERIOR LIGHTING and COMPONENTS | | | |
| 34-10-0400 | Exterior Lighting Requirements - General All light fixtures to be installed using nylon inserts unless directed otherwise. On secondary mode; grille, intersection, and center clear warning lights drop off. | 1 1 | SJC SJC |
| DOT LIGHTING | | | |
| 34-25-0100 | -- DOT Clearance and Marker Lighting | 1 | SJC |
| 34-25-0310 | /-- DOT Clearance and Marker Lighting (Upper Perimeter Module Walls) - Whelen OS | 1 | SJC |
| 50-00-7200 | /-- Whelen OS series - RED OSR00MCR (115800) Steady Burn | 2 | SJC |
| 50-00-7210 | /-- Whelen OS series - AMBER OSA00MCR (115801) Steady Burn | 7 | SJC |
| 34-25-0210 | -- Corner Lights Feature , (4) Lower Module Corners Use Micro Plastics round head Nylon inserts for these lights. | 1 | SJC |
| 12-10-0210 | -- Corner Guards, Four (4) ADP w/ Corner Light Cutouts | 4 | SJC |
| 34-25-0350 | /-- Corner Lights - Whelen OS Series | 1 | SJC |
| 50-00-7200 | /-- Whelen OS series - RED OSR00MCR (115800) Steady Burn | 6 | SJC |
| 50-00-7210 | /-- Whelen OS series - AMBER OSA00MCR (115801) Steady Burn | 6 | SJC |
| 50-00-6000 | -- Corner Light Bezel Cast LH14702-4 | 4 | SJC |
| FRONT MODULE WALL EXTERIOR LIGHTING | | | |
| | | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|------------|---|--|-----|-----|
| 35-16-0100 | | <i>/-- Lightbar, Front, Long Light Bar</i> | 1 | SJC |
| 35-90-0420 | S | <i>/-- Lightbar, Front, Long Light Bar</i> W/ ICC lights on the lightbar. | 1 | SJC |
| | | RL/CL/RL/CL/RL/CL/RL - Clear lenses (passenger side to drivers side) | | |
| | | Whelen 4500 lightbar - See Whelen Wizard | | |
| | | REAR MODULE WALL EXTERIOR LIGHTING | | |
| 38-41-0600 | | <i>/-- Lightbar, Rear, None Required, Whel Hal Warn.</i> | 1 | SJC |
| 45-10-0165 | | <i>/-- Warn. Light, Rear Passenger Side, Whel LED w/f</i> | 1 | SJC |
| 49-24-2215 | | <i>/-- Whelen, 7x9, Red, LED Flashing, Clear Lens, w/ flange</i> 90RR5FCR - Flashing/Programmable with lens | 1 | SJC |
| 50-00-1070 | | <i>/-- Whelen, 7x9 Chrome Flange for Super-LED</i> This flange is for the Super-LED model only | 1 | SJC |
| | | 90FLANGC | | |
| 45-12-0600 | | <i>/-- Scene Light, Rear Passenger Side, Whel</i> | 1 | SJC |
| 49-24-5315 | | <i>/-- Whelen, 7x9, Clear, Scene, w/ flange</i> 90E000ZR | 1 | SJC |
| 50-00-1050 | | <i>/-- Whelen, 7x9 Chrome Flange</i> 9EFLANGE | 1 | SJC |
| 45-15-0165 | | <i>/-- Warn. Light, Rear Center, Whel LED w/f</i> | 1 | SJC |
| 49-24-2225 | | <i>/-- Whelen, 7x9, Amber, LED Flashing, Clear Lens, w/ flange</i> 90AA5FCR - Flashing/Programmable with lens | 1 | SJC |
| 50-00-1070 | | <i>/-- Whelen, 7x9 Chrome Flange for Super-LED</i> This flange is for the Super-LED model only | 1 | SJC |
| | | 90FLANGC | | |
| 45-17-0600 | | <i>/-- Scene Light, Rear Driver Side, Whel</i> | 1 | SJC |
| 49-24-5315 | | <i>/-- Whelen, 7x9, Clear, Scene, w/ flange</i> 90E000ZR | 1 | SJC |
| 50-00-1050 | | <i>/-- Whelen, 7x9 Chrome Flange</i> 9EFLANGE | 1 | SJC |
| 45-20-0165 | | <i>/-- Warn. Light, Rear Driver Side, Whel LED w/f</i> | 1 | SJC |
| 49-24-2215 | | <i>/-- Whelen, 7x9, Red, LED Flashing, Clear Lens, w/ flange</i> 90RR5FCR - Flashing/Programmable with lens | 1 | SJC |
| 50-00-1070 | | <i>/-- Whelen, 7x9 Chrome Flange for Super-LED</i> This flange is for the Super-LED model only | 1 | SJC |
| | | 90FLANGC | | |

| PART NO | S | DESCRIPTION | QTY | ID |
|------------|---|---|-----|-----|
| 49-24-2215 | | <i>/-- Whelen,7x9,Red,LED Flashing, Clear Lens,w/ flange</i> 90RR5FCR - Flashing/Programmable with Color lens | 2 | SJC |
| 50-00-1070 | | <i>/-- Whelen, 7x9 Chrome Flange for Super-LED</i> This flange is for the Super-LED model only 90FLANGC | 2 | SJC |
| 38-89-9410 | | -- Rear Scene Lights, Activate on Opening of Rear Entry Doors | 1 | SJC |
| 38-89-9510 | | -- Rear Scene Lights, Activate on Reverse Gear | 1 | SJC |
| | | STOP, TAIL, TURN, AND BACKUP LIGHTING | 1 | SJC |
| 45-35-0615 | | <i>/-- T/B/T/BU Lights, Whelen,4x6,LED/Incand.,single turns,w/f</i> Includes one (1) pair of brake/tail lights, one (1) pair of turn signals, and one (1) pair of back-up lights mounted on the rear exterior module wall. | 1 | SJC |
| 49-22-3220 | | <i>/-- Whelen,4X6,Amber,Turn LED,w/ flange</i> 60A00TAR | 2 | SJC |
| 50-00-1020 | | <i>/-- Whelen, 4x6 Chrome Flange</i> 6EFLANGE | 2 | SJC |
| 50-00-8200 | | <i>/-- Deutsch water proof connector</i> | 2 | SJC |
| 49-22-4210 | | <i>/-- Whelen,4X6,Red,Brake/Tail LED,w/ flange</i> 60R00XRR - Maximum Intensity | 2 | SJC |
| 50-00-1020 | | <i>/-- Whelen, 4x6 Chrome Flange</i> 6EFLANGE | 2 | SJC |
| 50-00-8200 | | <i>/-- Deutsch water proof connector</i> | 2 | SJC |
| 49-22-4730 | | <i>/-- Whelen,4X6,Clear,Backup,w/ flange</i> 60J000CR | 2 | SJC |
| 50-00-1020 | | <i>/-- Whelen, 4x6 Chrome Flange</i> 6EFLANGE | 2 | SJC |
| 50-00-8200 | | <i>/-- Deutsch water proof connector</i> | 2 | SJC |
| | | CURBSIDE MODULE WALL EXTERIOR LIGHTING | 1 | SJC |
| 47-10-0165 | | <i>/-- Warn. Light, CS Front, Whel LED w/f</i> | 1 | SJC |
| 49-24-2215 | | <i>/-- Whelen,7x9,Red,LED Flashing, Clear Lens,w/ flange</i> 90RR5FCR - Flashing/Programmable with lens | 1 | SJC |
| 50-00-1070 | | <i>/-- Whelen, 7x9 Chrome Flange for Super-LED</i> This flange is for the Super-LED model only 90FLANGC | 1 | SJC |
| 47-20-0600 | | -- Scene Light, CS Front, Whel | 1 | SJC |
| 49-24-5315 | | <i>/-- Whelen,7x9,Clear,Scene,w/ flange</i> 90E000ZR | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|------------|---|--|-----|-----|
| 50-00-1050 | | <i>/-- Whelen, 7x9 Chrome Flange</i> 9EFLANGE | 1 | SJC |
| 47-30-0600 | | -- Scene Light, CS Rear, Whel | 1 | SJC |
| 49-24-5315 | | <i>/-- Whelen, 7x9, Clear, Scene, w/ flange</i> 90E000ZR | 1 | SJC |
| 50-00-1050 | | <i>/-- Whelen, 7x9 Chrome Flange</i> 9EFLANGE | 1 | SJC |
| 47-40-0165 | | <i>/-- Warn. Light, CS Rear, Whel LED w/f</i> | 1 | SJC |
| 49-24-2215 | | <i>/-- Whelen, 7x9, Red, LED Flashing, Clear Lens, w/ flange</i> 90RR5FCR - Flashing/Programmable with lens | 1 | SJC |
| 50-00-1070 | | <i>/-- Whelen, 7x9 Chrome Flange for Super-LED</i> This flange is for the Super-LED model only 90FLANGC | 1 | SJC |
| 49-20-2215 | | <i>/-- Whelen, 3x7, Red, LED Flashing, Clear Lens, w/ flange</i> 70R02FCR - Flashing/Programmable with Clear lens | 1 | SJC |
| 50-00-1000 | | <i>/-- Whelen, 3x7 Chrome Flange</i> 7EFLANGE | 1 | SJC |
| 47-40-9410 | | -- CS Scene Lights, Activate on Opening of Entry Door STREETSIDE MODULE WALL EXTERIOR LIGHTING | 1 | SJC |
| 47-60-0165 | | <i>/-- Warn. Light, SS Front, Whel LED w/f</i> | 1 | SJC |
| 49-24-2215 | | <i>/-- Whelen, 7x9, Red, LED Flashing, Clear Lens, w/ flange</i> 90RR5FCR - Flashing/Programmable with lens | 1 | SJC |
| 50-00-1070 | | <i>/-- Whelen, 7x9 Chrome Flange for Super-LED</i> This flange is for the Super-LED model only 90FLANGC | 1 | SJC |
| 47-70-0600 | | -- Scene Light, SS Front, Whel | 1 | SJC |
| 49-24-5315 | | <i>/-- Whelen, 7x9, Clear, Scene, w/ flange</i> 90E000ZR | 1 | SJC |
| 50-00-1050 | | <i>/-- Whelen, 7x9 Chrome Flange</i> 9EFLANGE | 1 | SJC |
| 47-80-0600 | | -- Scene Light, SS Rear, Whel | 1 | SJC |
| 49-24-5315 | | <i>/-- Whelen, 7x9, Clear, Scene, w/ flange</i> 90E000ZR | 1 | SJC |
| 50-00-1050 | | <i>/-- Whelen, 7x9 Chrome Flange</i> 9EFLANGE | 1 | SJC |

| PART NO S | DESCRIPTION | QTY | ID |
|------------|--|-----|-----|
| 47-90-0165 | -- Warn. Light, SS Rear, Whel LED w/f | 1 | SJC |
| 49-24-2215 | -- Whelen,7x9,Red,LED Flashing, Clear Lens,w/ flange | 1 | SJC |
| | 90RR5FCR - Flashing/Programmable with lens | | |
| 50-00-1070 | -- Whelen, 7x9 Chrome Flange for Super-LED | 1 | SJC |
| | This flange is for the Super-LED model only | | |
| | 90FLANGC | | |
| 49-20-2215 | -- Whelen,3x7,Red,LED Flashing, Clear Lens,w/ flange | 1 | SJC |
| | 70R02FCR - Flashing/Programmable with Clear lens | | |
| 50-00-1000 | -- Whelen, 3x7 Chrome Flange | 1 | SJC |
| | 7EFLANGE | | |
| 47-90-9400 | -- SS Scene Lights, Do NOT Activate on Opening of SS Compartment Doors | 1 | SJC |
| 47-90-9500 | -- Side Wall Scene Lights, Do Not Activate on Reverse Gear | 1 | SJC |
| | ARROW LIGHTBARS WARNING LIGHT and HEADLIGHT FLASHERS STROBE POWER SUPPLIES AUXILIARY LIGHTING | 1 | SJC |
| | | 1 | SJC |
| | | 1 | SJC |
| | | 1 | SJC |
| 53-34-0130 | Compartment Lights, 4" Recessed LED | 5 | SJC |
| | one (1) per compartment - if installed below the floor line, seal backside of flange w/ foam tape | | |
| | two (2) in SS#2 | | |
| 53-30-0130 | -- 4" Recessed 10 diode LED | 11 | SJC |
| | (1) in SS1 | | |
| | (3) in SS2 | | |
| | (3) in SS3 | | |
| | (3) in CS1 ALS | | |
| | (1) in CS2 | | |
| | Optronics BUL11CBX Clear 10 diode (118588) | | |
| | AUDIBLE WARNING DEVICES | | |
| 55-00-0010 | Refer to Chassis Section Above for Correct Siren Speakers | 1 | SJC |
| 55-10-0100 | Back-up Alarm, 97 dBa (Standard) | 1 | SJC |
| | EC520 (115164) | | |
| 55-12-0220 | Siren, Whelen 295HFSA7 | 1 | SJC |
| | 295HFSA7 (115350) | | |
| | COMMUNICATION PROVISIONS AND EQUIPMENT | | |
| 55-34-0100 | Antenna Base, Coax, Power and Ground Wires (Standard) | 1 | SJC |
| 55-00-0100 | -- Antenna Base, Coax, Power and Ground Wires | 1 | SJC |
| | RG58U coax with 10 ga. power and ground wires - label the base and coax end ANT#1 - terminate in the front console | | |
| | Hutton - Maxrad K-794 (if 17' req'd.) - or - Maxrad KE-794 (if 30' req'd.) | | |

| PART NO | S | DESCRIPTION | QTY | ID |
|------------|---|---|-----|-----|
| 55-00-0120 | | -- Antenna Coax | 1 | SJC |
| 55-00-0130 | | -- Antenna Power and Ground | 1 | SJC |
| 55-00-0140 | | -- Antenna Base | 1 | SJC |
| | | Hutton - Maxrad K-794 (if 17' req'd.) - or - Maxrad KE-794 (if 30' req'd.) | | |
| 55-00-0200 | | -- Breaker, 20 AMP | 1 | SJC |
| 55-36-0110 | | Antenna Base, Coax(es), Power and Ground Wires IATS | 1 | SJC |
| 55-00-0100 | | -- Antenna Base, Coax, Power and Ground Wires | 1 | SJC |
| | | RG58U coax with 10 ga. power and ground wires - label the base and coax end ANT#2 - terminate in the rear A/A | | |
| | | Hutton - Maxrad K-794 (if 17' req'd.) - or - Maxrad KE-794 (if 30' req'd.) | | |
| 55-00-0120 | | -- Antenna Coax | 1 | SJC |
| 55-00-0130 | | -- Antenna Power and Ground | 1 | SJC |
| 55-00-0140 | | -- Antenna Base | 1 | SJC |
| | | Hutton - Maxrad K-794 (if 17' req'd.) - or - Maxrad KE-794 (if 30' req'd.) | | |
| 55-00-0200 | | -- Breaker, 20 AMP | 1 | SJC |
| | | ENVIRONMENTAL SYSTEMS AND COMPONENTS | | |
| 57-10-0110 | | Heat / AC, Pro Air Ducted Combo System NOTE: before installing the ducts, spray or roll Temp Coat to the bottom side of the roof metal between the center hat section and the first "Z" rails to serve as a thermal break | 1 | SJC |
| 10-10-0550 | | -- Insulation Enhancement, Temp-Coat Ceramic Spray Ducted A/C 30 mil coating - spray on area of roof where Heat-A/C ducting will be run | 1 | SJC |
| 57-00-0210 | | -- Heat / AC Pro Air #935 12v Ducted Combo System HEAT/AC: Pro Air 935 w/ top discharge Pro Air #50 000 920 | 1 | SJC |
| 57-00-0300 | | -- Heat / AC Water Valve, Manual On Type I Chassis please mount manual valve and electric/vacuum valve inside A/C -Heat cabinet. Not under vehicle. On Type III chassis, mount manual valves behind removable panel in streetside #1. Mount electric/vacuum valve in A/C cabinet. Pro Air 800307 (105858) Manual | 2 | SJC |
| 57-00-0310 | | -- Heat / AC Water Valve, Electric Pro Air 63-000-180 (109869) Electric | 1 | SJC |
| 57-00-0400 | | -- Heat / AC Duct Adapters SJC 118759 (2) SJC 118758 (3) | 8 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|-------------------|---|--|----------|------------|
| 57-00-0410 | | -- Heat / AC Ducted Vents Pro Air 11-000-135 | 8 | SJC |
| 57-00-0420 | | -- Heat / AC Ducted Vent Retainers Pro Air 11-000-052 | 8 | SJC |
| 57-00-0425 | | -- Heat / AC Ducted Vent Adapter ACC #14563400A | 8 | SJC |
| 57-00-0430 | | -- Heat / AC Rigid Ducting 118755 118756 | 1 | SJC |
| 57-00-0435 | | -- Heat / AC Flexible Ducting SJC 105854 | 1 | SJC |
| 57-00-0440 | | -- Heat / AC Plenum SJC 118757 | 1 | SJC |
| 57-00-0460 | | -- Heat / AC Face Plate Prodesign 3092233 | 1 | SJC |
| 57-00-0470 | | -- Heat / AC Pad Larry's Upholstery | 1 | SJC |
| 57-12-0100 | | -- Heat / AC System Installed Above Walk/Pass-Thru | 1 | SJC |
| 57-24-0110 | | Exhaust Fans, Dual 12V Blowers (Standard) | 1 | SJC |
| 57-00-0100 | | -- Exhaust Fans, 12V Blower Detmar 751 (106333) | 2 | SJC |
| 57-00-0110 | | -- Cowl Vent - 4" Polished Attwood #1364A1 (115345) | 4 | SJC |
| 57-00-0120 | | -- Rectagular Vent - 8"x4" Polished Cast VC00011 (105578) | 1 | SJC |
| | | INTERIOR FEATURES and COMPONENTS | 1 | SJC |
| | | ENTRY DOOR FINISHES and COMPONENTS | 1 | SJC |
| 60-10-0100 | | Entry Doors Liners, 2-Piece Split Design | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|------------|---|--|--------|------------|
| 60-10-0260 | | /-- Entry Doors, Upper Liners, Aluminum w/ Multispec Face Attach using six (6) stainless or black oxide screws w/ finish washers | 1 | SJC |
| 69-10-2040 | | /-- Multispec Color: Greystone MS99-6072 With white background MS99-6072 | 1 | SJC |
| 60-10-0500 | | /-- Entry Doors, Kick Plates, ADP (Standard) | 1 | SJC |
| 62-10-0150 | | Entry Door Grab Bars, 1.25" S/S, 45° "V" Style Backer plates must be installed inside door before sending unit to paint. SJC 116526 | 3 | SJC |
| 62-20-0240 | | Wall Mounted Grab Bar(s) IATS, 1.25" x 12" Stainless Steel see prints Install at the rear entry doors Marson G304116521 (116521) | 2 | SJC |
| | | CEILING GRAB BARS | | |
| 62-30-0030 | | Grab Bar, Above Cot, 1.25" x 96" Stainless Steel (STD) all fastening points must fall on roof tubes or backer plates - See print | 1 1 | SJC SJC |
| 62-30-0230 | | Grab Bar, Above Squad Bench, 1.25" x 72" Stainless Steel all fastening points must fall on roof tubes or backer plates SJC 117514 | 1 | SJC |
| | | UPHOLSTERY | | |
| 68-10-0010 | | Upholstery, Seamless Vinyl, Solid Color (Standard) solid color seamless | 1 1 | SJC SJC |
| 68-10-0160 | | /-- Upholstery Color, Ash Gray | 1 | SJC |
| 68-10-0520 | | Padded Vinyl Trim (Standard) Vertical and horizontal edges above the monitor/defib and action area | 1 | SJC |
| | | FLOOR COVERING | | |
| 68-20-0130 | | Flooring, Lon Seal "Lon Floor Flecks", SWB | 1 | SJC |
| 68-20-0500 | | /-- Flooring Color, "Lon Floor Flecks", Moonstone #507 | 1 | SJC |
| | | SILL, SCUFF and COT WHEEL PLATES | | |
| 68-30-0100 | | Floor Sill Plates, Brushed Stainless Steel (Standard) #4 polished 20 Gauge stainless steel | 1 1 | SJC SJC |
| | | ATTENDANT'S SEAT | | |
| 69-08-0110 | | Attendant's Seat, EVS 1752 Seamless 6 Degree Back EVS Ltd. #1752 (108162) | 1 1 | SJC SJC |
| 69-08-1040 | | /-- Attendant's Seat Base, EVS Swivel Pedestal EVS Ltd. SB175 (107676) 1750 seat only - 2 position swivel | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|-------------------|----------|---|-----|-----|
| 69-10-0120 | | Interior Cabinetry, Plywood Commando | 1 | SJC |
| 69-10-0580 | | /-- Cabinetry Laminate Color: Folkstone Gray (Matte) #SG241 | 1 | SJC |
| | | CEILING FINISHING | 1 | SJC |
| 69-12-0120 | | /-- Headliner, Patient Compartment, Wood Backed Plastic | 1 | SJC |
| | | 115593 | | |
| | | ELECTRICAL (J-BOX) CONSTRUCTION | 1 | SJC |
| 69-14-0100 | | -- Electrical (J-Box) - Standard Configuration | 1 | SJC |
| | | ALS CABINET | 1 | SJC |
| 69-16-0100 | | -- ALS Cabinet - Standard Configuration | 1 | SJC |
| | | SQUAD BENCH and COMPONENTS | 1 | SJC |
| 69-22-0100 | | -- Squad Bench Base, Wood Construction Q | 1 | SJC |
| | | Includes seat belts for three seated occupants or one stretcher | | |
| 69-22-0920 | | /-- Floor Cove, 3" Recessed at Squad Bench Riser | 1 | SJC |
| 69-22-1100 | | -- Squad Bench Lid, Single, 3/4" Plywood | 1 | SJC |
| | | One (1) seat cushion | | |
| 69-22-1200 | | -- Squad Bench Interior, Plywood w/ White Lam | 1 | SJC |
| 69-22-1410 | | -- Embossed Rubber Liner Under Squad Bench | 1 | SJC |
| | | install on floor of storage space under squad bench - adhere rubber w/ Chemrex adhesive | | |
| | | Alert Mfg | | |
| 69-22-1810 | | /-- Pull-Out Drawer Under Squad Bench IATS | 1 | SJC |
| | | Box out cabinet area under squad bench w/ slide-out drawer as indicated in the prints | | |
| | | SLIDES: Thomas TB4932 Series - length depends upon drawer location | | |
| | | LATCH: Southco | | |
| 69-22-1910 | S | /-- Portable O2 Storage, Recessed Under Head Of Squad Bench | 1 | SJC |
| | | This will hold (2) "D" cylinder bottles horizontal in the bench. There will be a flip down door in the stepwell area. | | |
| 69-24-0340 | | /-- Net At Forward End of Squad Bench to Ceiling - Red | 1 | SJC |
| | | a net from squad bench to ceiling at forward end - seatbelt buckles at top and bottom - add backer plates in ceiling - thru-bolt at squad riser or lid w/ backer plates | | |
| | | Intertek | | |
| | | std door - ZRS-SJC011-28-SUJA | | |
| | | slider door - ZRS-SJC012-28-SUJA | | |
| 16-50-1600 | | /-- Backer Plates, in Ceiling For Squad Bench Web Barrier | 1 | SJC |
| | | See Fabrication prints for locations | | |
| 69-26-0110 | | /-- Cabinet Above Squad Bench | 1 | SJC |
| | | 8" depth (overall) unless otherwise noted. See Prints. Maximum Height 8 1/4". No struts. | | |
| | | Use stainless steel position hinge-3 per window | | |

| PART NO | S | DESCRIPTION | QTY | ID |
|-------------------|---|--|----------------------------------|--|
| | | Hinge from McMaster Carr #1460A1 / SJC #118196 | | |
| 69-30-0100 | | STREETSIDE CABINETRY <i>/-- Streetside Cabinetry - Standard Configuration</i> DELETE L3 cabinet | 1 1 | SJC SJC |
| | | CPR SEAT | | |
| 69-36-0010 | | -- Refer to Part #14-25-xxxx for CPR Seat Construction Info. | 1 | SJC |
| 69-36-0150 | | -- CPR Seat Interior, Plywood w/ White Lam | 1 | SJC |
| 69-36-0190 | | -- Embossed Rubber Liner Under CPR Seat installed on floor of storage space only - adhere rubber w/ Chemrex adhesive Alert Mfg. | 1 | SJC |
| | | ACTION / MONITOR-DEFIB. AREA COMPONENTS | | |
| 69-40-0120 | | <i>/-- Countertop, Action Area, Solid Surface Material</i> Build cabinets with flat counter tops (no lips) - bottom screws in back wall to be lowered and sunk flush so they are hidden by the solid surface top - color to match the action area counter | 1 1 | SJC SJC |
| 69-40-0610 | | <i>/-- Solid Surface Countertop Color - Dusk</i> | 1 | SJC |
| 69-40-0220 | | <i>/-- Countertop, Monitor/Defib, Solid Surface Material</i> Build cabinets with flat counter tops (no lips) - bottom screws in back wall to be lowered and sunk flush so they are hidden by the solid surface top - color to match the action area counter | 1 | SJC |
| 69-46-0110 | | <i>/-- Inside Access to Exterior Compartment IATS</i> See prints for location(s) Compartment at inside/outside access must be full depth. SS Rear compt | 1 | SJC |
| | | SHELVES and SHELVING COMPONENTS | | |
| 69-48-0135 | | <i>/-- Cabinet Shelves, .125" Aluminum</i> .125" smooth w/ "DA" finish, 1" bend up at front and rear edge - glue embossed rubber to shelf floor | 1 1 | SJC SJC |
| 69-48-0430 | | -- Cabinet Shelf Track, Unistrut Aluminum Upgrades all interior cabinet shelf tracks - including ALS cabinet Thomas-Austin Channel: #TB9111 Channel nuts: #TB9050 | 1 | SJC |
| | | DIVIDERS CABINET DOORS/WINDOWS and DRAWERS | | |
| 69-52-0100 | | -- Cabinet Doors/Windows, General (Plywood) See prints. All Sliding Plexiglas Doors to have stops placed in window track. | 1 1 1 | SJC SJC SJC |
| 69-54-0230 | | <i>/-- Cabinet Door(s) Hinged 3/8" Plexiglass ILO Hinged Wood</i> 3/8" Plexi - Upper ALS cabinet | 1 | SJC |
| 69-54-0850 | | <i>/-- Cabinet Windows(s) Hinged Restocking ILO Sliding Plexiglass</i> L1 and L3 | 2 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|-------------------|---|--|----------|------------|
| 69-58-0115 | | -- Plexiglas Color, Clear | 1 | SJC |
| 69-60-0100 | | -- Door/Drawer Latch, Southco Flush Pull see prints | 1 | SJC |
| 69-56-0416 | | -- Additional Cabinet Door(s) Hinged 3/8" Plexiglass 3/8" Plexi - Lower ALS cabinet section | 1 | SJC |
| | | MEDICAL SYSTEMS and COMPONENTS OXYGEN SYSTEM and EQUIPMENT | 1 | SJC |
| 71-14-0150 | | On-Board Oxygen Cylinder Bracket, ZICO QR-MV ILOS To be mounted on two (2) 56" adjustable shelf tracks. | 1 | SJC |
| 71-00-1940 | | -- On-Board Cylinder Bracket, ZICO QR-MV 106177 | 1 | SJC |
| 71-16-0100 | | Oxygen Cylinder Wrench (Standard) SJC #105888 | 1 | SJC |
| 71-20-0100 | | Oxygen Outlets, Ohio Style Quick Disconnect (2 in Action Area) | 1 | SJC |
| 71-00-1400 | | -- Oxygen Outlets, Ohio Style Quick Disconnect (2) in Action Area | 2 | SJC |
| 71-00-1010 | | -- Oxygen / Vacuum / Medical Air Trim Bezel Part of complete assembly | 2 | SJC |
| 71-22-0110 | | Oxygen Outlets, Ohio Style Quick Disconnect IATS | 1 | SJC |
| 71-00-1400 | | -- Oxygen Outlets, Ohio Style Quick Disconnect Sqd bench wall | 1 | SJC |
| 71-00-1010 | | -- Oxygen / Vacuum / Medical Air Trim Bezel Part of complete assembly | 1 | SJC |
| | | MEDICAL AIR SYSTEM and EQUIPMENT VACUUM SYSTEM and EQUIPMENT | 1 | SJC |
| 71-50-0100 | | Vacuum System, On-Board w/Ohio Style Outlet | 1 | SJC |
| 71-52-0100 | | -- Vacuum Outlet, (1) Ohio Style in Action Area | 1 | SJC |
| 71-00-1600 | | -- Vacuum Outlet, Ohio Style | 1 | SJC |
| 71-00-1010 | | -- Oxygen / Vacuum / Medical Air Trim Bezel Part of complete assembly | 1 | SJC |
| 71-54-0110 | | -- Vacuum Pump, Gast (Standard Types I and III) Installed in SS#2 w/ ADP guard unless specified otherwise | 1 | SJC |
| 71-00-1550 | | -- Vacuum Pump, Gast #22D11801011066 (112927) | 1 | SJC |
| 71-56-0100 | | -- Vacuum, Aspirator, RICO RS4X Disposable Rico 1001B (106315) | 1 | SJC |
| | | IV SYSTEM and EQUIPMENT | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|-------------------|---|---|----------|------------|
| 73-10-0100 | | IV Hangers, Cast Products Recessed in Ceiling | 1 | SJC |
| 71-00-0100 | | -- IV Hangers, Cast Products Recessed in Ceiling Cast Products #IV2008-1 (113850) | 2 | SJC |
| 16-50-0130 | | -- Backer Plates for Recessed IV Hangers | 2 | SJC |
| 73-40-0120 | | Trash Container, 2 Gallon, Installed | 1 | SJC |
| | | BIO-WASTE CONTAINERS | 1 | SJC |
| 71-00-0510 | | -- Trash Container, 2 Gallon Use the bottom section of a Sage two-gallon sharps container 115935 | 1 | SJC |
| | | COT AND STRETCHER EQUIPMENT | 1 | SJC |
| | | PRIMARY COTS | 1 | SJC |
| | | COT FASTENERS | 1 | SJC |
| 79-14-0100 | | -- Cot Fastener, Ferno-Washington 175-4 Dual Position (105725) | 1 | SJC |
| 79-16-0100 | | -- Cot Plates/Mounts, Install After Unit is Sold (demos only) Do not cut mounting holes in the floor or flooring - Installation instructions to be provided at time of install | 1 | SJC |
| 68-20-5000 | | -- Flooring, Do NOT Cut Holes for Cot Mounts (PN) Holes are to be cut for cot mounts after the unit is sold | 1 | SJC |
| | | STRETCHERS and EQUIPMENT | 1 | SJC |
| | | DECALS and LETTERING | 1 | SJC |
| | | K-SPEC LETTERING | 1 | SJC |
| 80-10-0130 | | Decals, K-Spec Lettering, Delete Deletes: (1) 4" mirror image AMBULANCE, (3) 6" AMBULANCE | 1 | SJC |
| | | STAR-OF-LIFE DECALS | 1 | SJC |
| 80-12-0150 | | Decals, Star-of-Life Package, Delete All Except Roof SOL Install roof SOL | 1 | SJC |
| 80-00-0150 | | -- Star of Life 32" Blue with white border 117806 | 1 | SJC |
| | | CUSTOM DECALS | 1 | SJC |
| 80-18-0500 | | Decals, "Marque" Logo Install... one on each fender, one on passenger rear - lower area one in Action Area one on curbside wall by side entry door | 1 | SJC |
| | | CUSTOM LETTERING | 1 | SJC |
| | | DECAL STRIPING | 1 | SJC |
| | | PAINT | 1 | SJC |

| PART NO | S | DESCRIPTION | QTY | ID |
|-------------------|---|---|-----|-----|
| 84-15-1000 | | Paint, Module, PPG - White (Standard) Wheels remain OEM color | 1 | SJC |
| | | MODULE PAINT | 1 | SJC |
| | | CHASSIS PAINT | 1 | SJC |
| | | PAINT STRIPING | 1 | SJC |
| | | MISCELLANEOUS EQUIPMENT and COMPONENTS | 1 | SJC |
| 90-10-0100 | | Stretcher Strap, Exterior Compartment (Standard) Installed in SS-rear compartment unless directed otherwise - nylon web strap w/ seat belt clip/buckle and two (2) footmans loops | 1 | SJC |
| 90-10-0210 | | <i>/-- Equipment Strap(s), Seat Belt Style IATS</i> Nylon web strap w/ seat belt clip/buckle and two (2) footmans loops | 1 | SJC |
| | | SS1 - position across the front of the O2 storage area. Connect at rear wall and the rear of vertical divider. | | |
| 90-14-0100 | | Interior Safety Signs (Standard) Two (2) NO SMOKING-OXYGEN EQUIPPED and two (2) FASTEN SEAT BELTS signs, one (1) each in the cab and in the patient compartment, 110V for each 110V outlet, cleaning sticker in Action Area, "Authorized Service Only" sticker in J Box. | 1 | SJC |
| 90-22-0100 | | Owner's Manual / Equipment Packet / OEM Manual | 1 | SJC |
| 90-24-0100 | | Fuel Surcharge | 1 | SJC |